

**Main Warehouse**

Tel: 021 905 7079

Fax: 021 905 7089

Website:

**Head Office**

Tel: 011 972 6526

Fax: 011 391 2854

[www.afdroofing.co.za](http://www.afdroofing.co.za)

## **Installation of Aluminium Valley Liner**



### **Step 1**

Ensure the valley boards are in position prior to installation of valley liner. Position the Valley Liner across the valley boards.



### **Step 2**

Secure the valley liner to the wooden battens using electroplated roofing nails – two nails at the top, two midway and two at the bottom of the valley. Bend the valley Liner edges inwards to prevent water splashing onto the wooden batten



### **Step 3**

Cut the valley Liner at the gutter end in a “V” shape to follow the line of the valley leaving a 5cm overlap. Bend the overlap into the gutter.